



# Mode Selector Key Switch



Mode Selector Key Switch



The switch is simple apparatus capable of switching the IS mode selection circuit allowing the Earth-Rite® RTR system to be used for grounding both road tanker/tank trucks and other metal objects of plant like Ex IBC, drums, etc.



## Operation

- > In normal operations namely road tanker/tank truck grounding the key is not required to be inserted into the lock in MSKS. When Ex IBCs and metal drums are to be grounded then the key can be inserted into the lock and turned to the second PLUS position (to the right). When in this position the key cannot be removed.
- > Once the Ex IBC and metal drum grounding is not required, turn the key back to the first RTR position and the key returned to the local area responsible person

\* Must only be used with the Earth-Rite® RTR System after consultation with Newson Gale

### Copyright Notice

The website and its content is copyright of Newson Gale Ltd © 2021. All rights reserved.

Any redistribution or reproduction of part or all of the contents in any form is prohibited other than the following:

- you may print or download to a local hard disk extracts for your personal and noncommercial use only
- you may copy the content to individual third parties for their personal use, but only if you acknowledge the website as the source of the material

You may not, except with our express written permission, distribute or commercially exploit the content. Nor may you transmit it or store it in any other website or other form of electronic retrieval system.

### Right to change

This document provides general information only and may be subject to change at any time without notice. All information, representations, links or other messages may be changed by Newson Gale at any time without prior notice or explanation.

Newson Gale is not obliged to remove any outdated information from its content or to expressly mark it as being outdated. Please seek the advice of professionals as necessary regarding the evaluation of any content.

### Disclaimer of liability

The information provided in this Datasheet is provided by Newson Gale without any representations or warranties, expressed or implied, as to its accuracy or completeness. The liability of Newson Gale for any expenses, losses or actions incurred whatsoever by the recipient as a result of the use of this Datasheet shall be excluded.

Leading the way in hazardous area static control



www.newson-gale.com

1/1

United Kingdom  
**Newson Gale Ltd**  
 Omega House  
 Private Road 8  
 Colwick, Nottingham  
 NG4 2JX, UK  
 +44 (0)115 940 7500  
 groundit@newson-gale.com

United States  
**IEP Technologies LLC**  
 417-1 South Street  
 Marlborough, MA 01752  
 USA  
 +1 732 961 7610  
 groundit@newson-gale.com

Deutschland  
**IEP Technologies GmbH**  
 Kaiserswerther Str. 85C  
 40878 Ratingen  
 Germany  
 +49 (0)2102 58890  
 erdung@newson-gale.de